




# Air angle die grinder



NO	DESCRIPTION
1	HOUSING
2	THROTTLE LEVER
3	ROLL PIN
4	VALVE
5	VALVE SPRING
6	VALVE PLUG
7	AIR REGULATOR
8	VALVE BUSHING
9	O-RING
10	O-RING
11	O-RING
12	O-RING
13	BALL BEARING
14	REAR END PLATE
15	ROTOR
16	ROTOR BLADE
17	CYLINDER
18	BUSHING
19	WASHER
20	PIN
21	FRONT END PLATE
22	BALL BEARING
23	PIN
24	BEVEL GEAR
25	CONNECT NUT
26	CLAMP NUT
27	ANGLE HEAD
28	BALL BEARING
29	BEVEL GEAR
30	WOODRUFF KEY
31	WORK SPINDLE
32	LOCK NUT
33	1/4" COLLET
34	1/8" COLLET
35	COLLET JACKET
36	GREASE CAP
37	MUFFLE COVER
38	AIR INLET